

CAMPUS CRUISER ASSEMBLY INSTRUCTIONS

Step 1: Take one cart and set it wheels down on the ground. Remove cable ties and tape from the base pad.



Step 2: Take one sleeve, with the sealed edge up, and separate the two sides to open into a rectangular shape.



Step 3: Place the sleeve over the cart and slide the sidewalls down into the frame groove so that the bottom edge of the sleeve fits around the grey base pad. Push down to make sure the sleeve is resting on the metal cart.



Step 4: Insert the heavy-duty cable tie through one hole and push back through the second hole on the shorter side of the cart. Secure the cable tie by inserting the flat end through the slot on the other end of the tie. Make sure the cable tie is **NOT** twisted. Pull tight and cut off the excess material if desired.



NOTE: *Only heavy-duty 0.76"+ thick cable ties are to be used. Standard zip ties can break easily when the bin is loaded down.*

NOTE: *Do not lift a full cart up stairs, hand holes are only for lifting over curbs and other small obstacles.*

www.campuscruisercart.com
L-S Industries, Inc. | 1-800-825-2561
8902 Valgro Rd. Knoxville, TN 37920

CAMPUS CRUISER ASSEMBLY INSTRUCTIONS (cont.)

To disassemble the bin, simply release the latch on the re-usable cable ties (or cut if it's easier) and lift the sleeve off of the cart. The sleeves can be laid on the ground, or on the original pallet and stacked up. The carts can be stored any way you like but placing them upside down in an alternating pattern as you stack them (see photo in step 1) will likely be the most efficient use of space. You may want to protect the metal with a piece of foam, paper, etc. so that the carts do not scratch each other.

100 carts should take up approximately 132 square feet of space. Sleeves are 69"L x 30"W x 1"H and carts are 39.25"L x 28.25"W.

To re-order parts, contact Customer Service at 1-800-825-2561 x105.

PARTS LIST

PART NAME	ITEM NUMBER
Sidewall Sleeves 39"x28"x30"	10MM 39X28X30 SLEEVE
Fully Assembled Cart 39.5"x28.5"	ALUMINUM CRUISER CART
3" swivel caster 27-UPB-0312-S	7270310704
4" swivel caster 45-UPB-0420-S-Q	7450410071 (upgrade)
10mm base pad 37.80" X 26.77"	10MM 960X680 BASEPAD
Rivets for base pad (4)	Avdel Blind Pop Rivets, Part #AD610BSLF200
175lb Cable ties 11/32"W x .076" Thick	ULINE Item # S-14020BL (reusable)

CAMPUS CRUISER Limited Warranty

L-S Industries, Inc. warrants the Campus Cruiser from defects in material and workmanship for a period of 6 months from date of original purchase. Warranty assumes that the product is only used for the intended purpose of university student move-in support, and only in the university environment.

Warranty claims should be submitted to L-S Industries Customer Service by phone at 1-800-825-2561 x105 or by email at jledford@l-si.com.